


Gebrauchsanweisung

58 3778


 (es, en, de, pt)


1) 17 2762


2) 16 9753



- 1) 06 0083
- 2) 17 2274
- 3) 06 0115







TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS			
		KF	GF
Verdichter/Compressor/Compresseur/Compresor		Danfoss	Danfoss
Typ/Type/Tipo		TLES7KK2	TLES9KK2
Förderleistung/Delivery/Debit/Aspiración l/h		1168	1589
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A		4,5	4,5
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		18,9	16,5
Hi/aux.		15,3	19,9
Temp.Reyler/Thermostat/Termostato			
Typ/Type/Tipo			
Reglerstellung/Position/Conexión			
Schaltwerte/Switching values/			
Valeurs de commutation/Desconex.			
(..abtaven' od)			
Füllmenge/Fill. quantily/Charge/Carga R600a	g	19	40
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	70	90
Ventilator/Blower/Ventilateur			
Widerstand/Resistance	Ohm		