






Libro de instrucciones
59 1377
(de,en,es,pt)

1) 17 0617
2) 17 3206





Pos.	Matsushita			
	DA125E			
1	14 2012			
2				
3				
4	17 4432			
5				
6	48 1077			
7	05 0166			
8	44 1196			
9				
10				
11				
12				
13				

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor	Matsushita			
Typ/Type/Tipo	DA125E			
Förderleistung/Delivery/Debit/Aspiración l/h				
Anlaufstrom/Starting current/Cour.démarrage/Int.arranq. A	9,30			
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	12,11			
Hi/aux.	13,80			
Temp.Reyler/Thermostat/Termostato	Danfoss			
Typ/Type/Tipo	077B6733			
Reglerstellung/Position/Conexión	MIN. MAX.			
Schaltwerte/Switching values/ ..ein/conex.°C	+5			
Valeurs de commutation/Desconex. ..aus"/descon.	-22 -34			
(..abtaven' od) ..alarm'				
Füllmenge/Fill. quantily/Charge/Carga R600a	g	*		
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	129		
Heizung/Heater/Chauflage/Resistenc.descong.				
Widerstand/Resistance/Resistencia	Ohm			
Leistung/Power/Puissance/Potencia	W			
Ventilador/Blower/Ventilateur/Ventilador				
Widerstand/Resistance/Resistencia	Ohm			
Magnetventil/Magnetic valve/Electrovanne/Electrovalvula				
Widerstand/Resistance/Resistencia	Ohm			
Spannung/Voltage/Tension/Tensión	V			
Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador				

* Siehe Typenschild / See identification plate / Voir plaquette de caractéristiques / Ver plaqueta de características