

Service
Service
Service



Philips Domestic Appliances and Personal Care

Service Manual 4322 277 00082 is herewith cancelled

Service Manual

PRODUCT INFORMATION

Power consumption	: 250 W
Voltage and frequency	: 230 V / 50 - 60 Hz
Cord length	: 130 cm
Speed unloaded	: 25.000 rpm
Volume beaker	: 1.000 ml
Weight in F-box	: 1.2 kg
Dimensions F-box	: 144 x 144 x 402 mm
Colour version /6	: Ivory / Pearl Blue / Zink Brown
/32	: Green Blue Shade / Dusky Orchid


SERVICE INFORMATION


Remove cover 2 to open the appliance.

Product meets the requirements regarding interference suppression on radio and TV.

After the product has been repaired, it should function properly and has to meet the safety requirements as laid down officially established at this moment.

HR 1350





1	9965 000 01629	power unit	/6
	9965 000 08082	power unit	/32
2	9965 000 01630	screw cap	
3	9965 000 01631	pcb	
4	9965 000 01632	drive coupling	
5	9965 000 01633	wall hook EU	/6
	9965 000 08083	wall hook EU	/32
	9965 000 01634	wall hook GB	
6	9965 000 01713	rubber ring	
7	9965 000 01635	synth. bar	/6
	9965 000 08084	synth. bar	/32
8	4822 418 40924	beaker and lid (standard)	