



Philips Consumer Lifestyle

Service Manual

PRODUCT INFORMATION

- Product meets the requirements regarding interference suppression on radio and television.
- After the product has been repaired, it should function properly and has to meet the safety requirements as laid down officially established at this moment.

TECHNICAL INFORMATION

- SMPS Adapter
- Primary Adapter Voltage : 100 - 240 V
- Primary Adapter Frequency : 50 - 60 Hz
- Primary Adapter Power : 10 W
- Secondary Adapter Voltage : 8,5 V
- Secondary Adapter Current : 600 mA

DISASSEMBLY- AND RE-ASSEMBLY ADVISE

- No specific issues.

REPAIR INSTRUCTION

- No specific issues.

OPTIONAL (accessories)

- No specific issues.



Pos	Service code	Description
1	4203 035 88040	Blender Bar
2	4203 035 87200	Whisking Accessories
3	4203 035 87210	Beaker Lid
4	4203 035 87220	Beaker 1,0 L
5	4203 035 87230	Chopping Interface
6	4203 035 87240	Chopping Knife
7	4203 035 87250	Chopping Bowl
8	4203 035 87260	Knife protection for Blender Bar
9	4203 035 88100	Charger incl. Plug Eu
	4203 035 87310	Charger incl. Plug ARG