

Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

- Small-volume brush head
- Active tip
- Controlled Pressure System
- End-rounded bristles
- Storage for brush head on the charger
- Number of brushes inserted in luxury carton : 1
- Topography colour V-shape : green

TECHNICAL DATA

Voltage	: 200 - 240 V, 50 - 60 Hz
Power consumption	: 3 Watts
Speed (top)	: up to 15.000 brush strokes per minute
Pressure control click at	: 250 gr.
Charging time (empty to full)	: 16 hours
Operating time (full to empty)	: ± 25 minutes
Battery type	: NiCd

SERVICE INFORMATION

Hand unit tooth brush (1)

Never open the hand unit of the tooth brush, because the unit is not water tight anymore.

In case of a defect, the complete unit must be replaced.

Charging unit (2)

In case of a defective charging unit or cordset, the complete charging unit must be replaced.


NOTES

For standardisation reasons, the hand unit is replaced by the hand unit of the HX1525. The hand unit of the HX 1525 has a charging light.

If the battery in the toothbrush is being charged, the pilot light is green.

When discarding the appliance, remove the built-in rechargeable battery. The battery should be completely empty of charge.

Product meets the requirements regarding interference suppression on radio and TV.



Pos	Description	Service code
1	Rechargeable hand unit (NiCd)	4822 218 12089
2	Charging unit 200 - 240 V. Euro plug	4822 219 10755
	Charging unit 220 V. Korean plug	4822 219 10756
3	Set of brushes (2 pcs in blister pack)	4822 479 20271