

Service  
Service  
Service

QG3040  
QG3060  
QG3080



Philips Consumer Lifestyle

# Service Manual

## PRODUCT INFORMATION

### Features:

- Beardtrimmer and Hairclipper attachment.
- 2D Contour Tracking Beardtrimmer Comb; Comb adapt to the contours of the face.
- Hair Length Selector; for adjustability of the Beardtrimmer Comb with 9 settings - resulting 9 different hairlengths that can be cut between 2 mm and 18 mm.
- Profiler attachment; for trimming the neckline and sideburns.
- Nose / ear / eyebrow Grooming Attachment.
- Charging indication (LED on Adapter).
- Maintenance free cutting elements: no oiling required.
- 3-Dimensional Rounded Chromium Steel Blades.
- Hairclipper Comb with 9 different settings - resulting 9 different hairlengths that can be cut between 4 mm and 20 mm.
- Precision shaper accessory

### Safety

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

## TECHNICAL INFORMATION

- Power system : Rechargeable
- Batteries : 1 x AA NiCd
- Charging period : NiCd : 10 hours
- Capacity : NiCd battery : up to 40 minutes

## DISASSEMBLY- AND RE-ASSEMBLY ADVISE

- No specific issues.

## REPAIR INSTRUCTION

- No specific issues.

## OPTIONAL (accessories)








- No specific issues.
- SAP Coding: QG3040  
QG3060  
QG3080

## NOTES :

- \* In order to guarantee the longest possible working life of the battery :
  - do not charge for more than 24 hours
  - do not keep the charging unit permanently plugged in
  - discharge the battery completely once a year by letting the motor run until it stops
- \* If the battery is empty and the consumer wants to trim his beard, the trimmer has to be charged for at least 3 hours to have enough power for one trim (10 min.)
- \* The appliance should be charged again, when not used for a long period

## PARTS LIST & EXPLODED VIEW

**QG3040**  
**QG3060**  
**QG3080**



Pos	Service code	Description	QG3040	QG3060	QG3080
1	4203 035 73080	Beardtrimmer Comb	X	X	
	4203 035 79960	Beardtrimmer Comb			X
2	4203 035 79970	Hairclipper Comb		X	X
3	4203 035 73100	Beardtrimmer / Hairclipper Accessory	X	X	
	4203 035 79980	Beardtrimmer / Hairclipper Accessory			X
4	4203 035 73110	Profiler Accessory	X	X	
	4203 035 79990	Profiler Accessory			X
5	4203 035 73120	Nosetrimmer Accessory	X	X	
	4203 035 79750	Nosetrimmer Accessory			X
6	4203 035 78390	Adapter - EU	X	X	X
	4203 035 78400	Adapter - UK	X	X	X
	<b>4203 035 83050</b>	Adapter - PRC	X	X	X
	4203 035 78410	Adapter - CDN	X	X	X
	<b>4203 035 61420</b>	Adapter - MEX	X	X	X
	<b>4203 035 54870</b>	Adapter - BRA	X	X	X
7	4203 035 73130	Precision shaper Accessory			X

**■** = changed