

Service
Service
Service



Philips Consumer Lifestyle

Service Manual

PRODUCT INFORMATION

Safety:

- After the product has been repaired, it should function properly and has to meet the safety requirements as laid down and officially established at this moment.

TECHNICAL INFORMATION

- No specific issues

DISASSEMBLY- AND RE-ASSEMBLY ADVISE

- No specific issues

REPAIR INSTRUCTIONS


- No specific issues

OPTIONAL (accessories)

- No specific issues

PARTS LIST & EXPLODED VIEW

SCD510
SCD520



Pos	Service code	Description	SCD510	SCD520
1	4203 035 84760	Belt Clip - Parent Unit	X	X
2	4203 035 84770	Battery cover - Parent Unit	X	X
3	4203 035 84780	Battery cover - Baby Unit	X	X
4	4203 035 84790	Neck Strap	X	X
5	4203 035 84800	Battery - NiMH	X	X
	9965 100 31439	Battery Pack - NiMH - US version	X	X
6	4203 035 84810	Charging Stand - Parent Unit		X
7	9965 100 30979	Adapter - Baby Unit - EU	X	X
	9965 100 30978	Adapter - Baby Unit - UK	X	X
	4203 035 84740	Adapter - Baby Unit - AUS / NZ	X	X
	4203 035 86330	Adapter - Baby Unit - USA	X	X
	9965 100 31438	Adapter - Baby Unit - MX/PA	X	X
8	9965 100 30977	Adapter - Parent Unit - EU	X	
	9965 100 30981	Adapter - Parent Unit - EU		X
	9965 100 30976	Adapter - Parent Unit - UK	X	
	9965 100 30982	Adapter - Parent Unit - UK		X
	4203 035 84710	Adapter - Parent Unit - AUS / NZ	X	
	4203 035 84720	Adapter - Parent Unit - AUS / NZ		X
	4203 035 86320	Adapter - Parent Unit - USA	X	
	4203 035 86340	Adapter - Parent Unit - USA		X
	9965 100 31441	Adapter -Parent Unit - MX/ PA	X	X

■ = changed