



249



184


Ø 180



Ø 145




Ø 145

Ø 180





249




184

DUAL



Ø 145


151



Ø 145

OV





249

184

151




40


Ø 145


DUAL

OVAL


Ø 145









Ø 145




Ø 180




Ø 210



Ø 140 /
250 OVAL



Ø 180 /
120 DUAL



Ø 210 /
125 DU

HIGHLIGHT HEATING (OPTIONAL)

HOB ASSEMBLY PART

POSITION NUMBER	PART NAME
4	SCREW (CONEHEADED, 3.9*9.5)
8	HOT SURFACE INDICATOR LIGHT
22	HOT SURFACE INDICATOR LIGTH HOLDER(C SERIE)
30	TERMINAL BOX
31	POWER CORD (UNPLUGGED,WHITE)
40	SCREW (KNURLED, 3.5*9.5)
80	ELECTRICAL KOMPONENT CONTACT SCREW
90	KNOB-ELECTRICAL
150	HEATING ELEMENT ASSEMBLY SPRING T TYPE(10MM,14MM,22 MM)
151	HEATING ELEMENT ASSEMBLY SPRING V TYPE
167	KNOB GASKET (CERAN)
184	HIGHLIGHT HEATING
188	ENERGY REGULATOR
200	FR HOB BOTTOM COVER
216	TOUCH CONTROL UNIT
222	HOB ASSEMBLY SPRING
249	CERAMIC GLASS ASSEMBLY
273	SD HOB BOTTOM COVER
274	FRTR SUPPORT
275	REGLER COVER
276	SIDE TOUCH CONTROL UNIT SUPPORT
277	REGLER SUPPORT
278	TERMINAL BOX HEAT SHIELD

