

This diagram illustrates the exploded view of a Bosch dishwasher, showing the main body, door, racks, and various internal components. The parts are labeled with numbers and letters, indicating their assembly sequence and location. Key components include the top panel (910 0), door (700 0), racks (241 0, 242 0), and the main body (701 1). The diagram also shows the internal wiring (791 0, 791 1), water inlet valve (791 2), and pump assembly (791 3). The bottom panel (004 0) and various screws and fasteners are also shown.

08001203

DIBUJO EXPLOSIONADO

