


LISTA DE RECAMBIOS

Pos-Nr.	12NC	DESCRIPCION
002 0	4812 459 38057	TRAMPILLA GW
002 1	4812 459 38058	BISAGRA GW
004 0	4812 440 19625	BANDEJA GOTEÓ
010 0	4812 459 48175	MARCO GW
010 1	4812 440 11637	ARMAZON
011 0	4812 462 48054	PIE
012 8	4812 528 78075	PIE
021 0	4812 440 10838	PANEL FRONTAL WH GW
022 0	4812 440 10839	PANEL LATERAL GW
022 1	4812 440 10841	panel lateral GW
024 0	4801 101 00103	TAPA POST.
040 0	4812 417 19155	BISAGRA GW
061 0	4812 466 88995	CONTRAPESO
061 1	4812 466 88996	CONTRAPESO
061 2	4812 466 88492	CONTRAPESO
081 4	4812 529 18043	AMORTIGUADOR
086 4	4812 529 18045	PERNO
086 5	4812 529 18052	ARMORTIGUADOR
100 1	4812 440 10842	TAPA GW
100 3	4812 440 10843	CONTRAPUERTA GW
100 5	4812 440 10845	TAPA SUPERIOR CTO. GW
110 4	4812 498 18249	ASA GW
130 0	4812 417 19193	PESTILLO PUERTA GW
191 0	4812 466 68596	GOMA de CUBA 3cm
191 1	4801 111 00817	ANILLO
200 0	4812 418 18692	CUBA,LAVADORA
200 1	4801 111 02216	RECIPIENTE LR 5 pins, kit
201 0	4801 101 00027	CUBIERTA
220 0	4801 111 02218	TAMBOR LR 210/M8, kit
221 1	4812 310 18843	Kit
223 0	4801 101 00104	ALETA TAMBOR
271 0	4812 358 18204	CORREA
272 0	4812 528 88083	POLEA 298 mm
290 0	4812 532 68078	GOMA ESCOTILLA
301 0	4801 111 02315	PANEL DE MANDOS AWE 6521
331 0	4812 414 58306	MANDO TIMER
331 2	4812 414 58307	RESORTE MANDO TIMER
332 0	4812 410 29501	BOTONERA 4 Opc.
333 0	4812 410 29503	BOTONERA
333 1	4812 410 29504	BOTONERA Opc.
400 0	4801 101 00045	MOTOR MCA 45/64-148/ALB1,1000
421 0	4812 121 18285	FILTRO INTERF.
421 2	4812 404 38679	SOPORTE RFI
430 0	4812 360 18577	BOMBA VACIAD.
451 0	4812 259 28919	CALEFACTOR 2050W, 230V + NTC
490 0	4819 321 18136	CABLE DE RED 2M SA
490 1	4812 321 28367	REGL.CONEX.LINE
521 0	4801 111 02333	UNIDAD CONTROL DOMINO
521 0	4812 214 70658	UNIDAD CONTROL
571 0	4812 281 28468	ELECTROVALV.


Pos-Nr.	12NC	DESCRIPCION
571 1	4812 281 18069	CUBIERTA
581 0	4812 271 28554	PRESOSTATO
620 0	4812 239 58046	MODULO E3
630 0	4812 271 38519	CERRADURA
653 0	4812 134 18077	GUIA LUZ
653 1	4812 134 18078	GUIA LUZ
691 0	4812 282 19485	SENSOR NTC
701 0	4812 530 29329	TUBO LLENADO
702 2	4812 530 29453	MANGUERA
707 0	4812 526 48244	BOQUILLA
707 1	4812 526 48049	FIJADOR
712 4	4812 418 68302	SIFON
712 6	4812 418 68164	CLIP
712 9	4812 418 68404	RECIPIENTE
753 0	4812 418 68187	CAMARA DE AIRE PRESOSTATO
754 0	4812 530 28938	TUBO CUBA/BOMBA
754 1	4812 530 28832	BOLA VALVULA
760 0	4812 480 58403	FILTRO
781 0	4819 530 29035	TUBO VACIADO
782 0	4812 530 28941	MANGUERA PRESOSTATO
787 0	4812 530 29309	MANGUERA SALIDA VAPORES
787 1	4812 530 29311	CUBIERTA
794 0	4812 530 58098	GUARNICION
900 0	4819 401 18686	SUJETA-MANGUERA
900 1	4812 401 18431	FIJADOR
900 2	4812 255 18304	SOPORTE TUBO
900 3	4819 401 18529	SUJETA-MANGUERA
901 0	4812 401 18462	SUJETA-MANGUERA
910 0	4812 502 48347	TORNILLO 3,5x14
910 1	4812 502 38151	TORNILLO 4X14
910 3	4812 502 18817	TORNILLO POLEA M8x23
910 4	4812 502 18423	TORNILLO PT 7X15
910 5	4812 502 18705	TORNILLO M8x35
910 6	4812 505 18367	TUERCA M 8
921 0	4812 400 18047	ARANDELA
930 1	4812 492 48171	MUELLA TORS.
930 2	4812 492 48162	RESORTE
941 0	4812 310 19144	COJINETE kit ALL 1100
953 0	4812 325 68001	ARO DE CIERRE
962 0	4812 440 98142	CUBIERTA
962 2	4812 440 11424	SEPARADOR
965 0	4812 462 79974	TAPA
990 0	4812 310 19224	MASILLA SELLAR CONTRAPESO
990 2	4812 310 18506	MASILLA SELLAR
993 0	4819 530 29028	CURVA TUBO
993 1	4812 290 18025	FIJADOR

DIBUJO EXPLOSIONADO



8593 651 18090

DIBUJO EXPLOSIONADO



8593 651 18090